

## CL-WiFi

### Wireless Interface for 788T Recorder



#### Description

The CL-WiFi is a hardware accessory for the 788T recorder. WiFi-capable mobile devices with the CL-WiFi application communicate with the CL-WiFi as a standard access point, to control the 788T.

#### Specifications

- Includes 6-inch C.Link Cable and Removable WiFi antenna.
- The maximum cable length between CL-WiFi and recorder is 20 feet
- Dimensions 1.25" x 2" x 2" (H x W x D)

#### FCC Statement

This device complies with the FCC Rules, Part 15, Class B.  
FCC ID: XM5-SM2144N1  
IC: 8516A-SM2144N1

#### Note

The CL-WiFi is powered and programmed from the 788T recorder.

#### How to Use

---

*Complete documentation for the CL-WiFi interface is included in the 788T user guide.*

---

- Screw on the included antenna.
- Connect the CL-WiFi to the 788T C. Link input connection using the included C. Link cable.
- Set the 788T to CL-WiFi mode from the 788T menu item "Firewire/USB: Connection".
- Configure the SSID and IP address of CL-WiFi from the 788T setup menu.
- Configure mobile device to connect to the WiFi access point created by the CL-WiFi. Wait for the mobile device to indicate a WiFi connection.
- Launch the CL-WiFi application on the mobile Device.

---

Complete details on CL-WiFi programming and control are available in 788T User Guide.

---